

EK-PM32E-PS-001

DECstation 5000 Model
100 Series Pocket
Service Guide

digital equipment corporation
maynard, massachusetts

August 1991

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by Digital or its affiliated companies.

Copyright ©1990, 1991 Digital Equipment Corporation
All Rights Reserved
Printed in U.S.A.

USA

This equipment generates, uses, and may emit radio frequency energy. The equipment has been type tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such radio frequency interference. Operation of this equipment in a residential area may cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

The following are trademarks of Digital Equipment Corporation:

DEC	MicroVMS	VAXBI
DECnet	PDP	VAXcluster
DECstation	ULTRIX	VAXstation
DECsystem	ULTRIX-32	VMS
DECUS	UNIBUS	VT
MicroVAX	VAX	digital [™]

Contents

Using This Guide	xiii
Chapters	xv
Conventions	xvii

1 TROUBLESHOOTING INFORMATION

Error Messages	1-2
Test failure messages ...	1-3
Console exception messages	1-6
Memory test error messages	1-7
Addresses	1-8
Slot numbers	1-8
Memory addresses	1-9
Hardware physical addresses	1-10
ULTRIX Error Logs	1-12

Memory parity error log	
fields	1-13
CPU write timeout	1-14
Bus timeout	1-14
Diagnostic LEDs	1-15
Registers	1-16
Cause register	1-16
System registers	1-18

2 TROUBLESHOOTING TOOLS

Self-tests	2-1
Console Mode Tests	2-2
Console commands	2-2
t command	2-4
SCSI controller (cntl)	
test	2-8
SCSI send diagnostics (sdiag)	
test	2-9
External loopback	
test	2-10
Transmit and receive	
test	2-12
SCC pins test	2-14
Test scripts	2-17
Flow Charts	2-18

3 PART NUMBERS

Figures

2-1	Troubleshooting procedure, 1 of 2	2-18
2-2	Troubleshooting procedure, 2 of 2	2-19
2-3	When the LED display is 1111 1111, 0011 1111, 0011 1110, or 0011 1101, 1 of 2 . . .	2-20
2-4	When the LED display is 1111 1111, 0011 1111, 0011 1110, or 0011 1101, 2 of 2 . . .	2-21
2-5	When the LED display is 0011 0110	2-22
2-6	When the LED display is 0010 0011, 0001 0011, 0000 0011, or 0000 0000	2-23
2-7	When the LED display is 0011 1011, 0010 1011, 0001 1011, or 0000 1011, 1 of 2	2-24
2-8	When the LED display is 0011 1011, 0010 1011, 0001 1011, or 0000 1011, 2 of 2	2-25
2-9	When the monitor has no display, 1 of 2	2-26
2-10	When the monitor has no display, 2 of 2	2-27
2-11	When hardware does not appear in the cnfg display, 1 of 3	2-28

2-12	When hardware does not appear in the cnfg display, 2 of 3	2-29
2-13	When hardware does not appear in the cnfg display, 3 of 3	2-30
2-14	Troubleshooting memory modules	2-31
2-15	Troubleshooting SCSI controllers and devices, 1 of 2	2-32
2-16	Troubleshooting SCSI controllers and devices, 2 of 2	2-33
2-17	Troubleshooting an Ethernet controller, 1 of 2	2-34
2-18	Troubleshooting an Ethernet controller, 2 of 2	2-35
2-19	Troubleshooting a printer, modem, or other serial line device, 1 of 2	2-36
2-20	Troubleshooting a printer, modem, or other serial line device, 2 of 2	2-37
2-21	Troubleshooting the power supply	2-38
2-22	If the system unit overheats	2-39
2-23	Troubleshooting the keyboard and mouse, 1 of 2	2-40
2-24	Troubleshooting the keyboard and mouse, 2 of 2	2-41
2-25	When ULTRIX is running but the monitor has no display, 1 of 3	2-42

2-26	When ULTRIX is running but the monitor has no display, 2 of 3	2-43
2-27	When ULTRIX is running but the monitor has no display, 3 of 3	2-44
3-1	DECstation 5000 Model 100 Series Major FRUs ...	3-2

Tables

1-1	Base system test error messages	1-4
1-2	Slot numbers in commands and messages	1-8
1-3	Memory module slot address ranges	1-9
1-4	Hardware physical addresses	1-10
1-5	Error log event types	1-12
1-6	LED error codes	1-15
1-7	Cause register exception codes	1-17
1-8	System registers	1-18
1-9	Memory Error Register (MER) 0x0C400000	1-19
1-10	System Interrupt Register (SIR) 0x1C040110	1-20
2-1	Console command functions	2-2
2-2	Base system module tests and utilities	2-5
2-3	SCSI controller error codes	2-8

2-4	SCSI send diagnostics error codes and descriptions	2-9
2-5	External loopback test codes and descriptions	2-11
2-6	SCC transmit and receive test codes and descriptions	2-13
2-7	Pin pairs tested by loopback connectors	2-15
2-8	SCC pins test codes and descriptions	2-16
3-1	Part numbers: Basic system components	3-3
3-2	Part numbers: Internal drives	3-4
3-3	Part numbers: TURBOchannel option modules	3-5
3-4	Part numbers: Monitors	3-6
3-5	Part numbers: Input devices	3-8
3-6	Part numbers: Loopback connectors, plugs, test media, and small hardware ..	3-9
3-7	Part numbers: Cords, cables, and connectors	3-10
3-8	Part numbers: Hardware documentation	3-12

Using This Guide

This guide contains the information that you need for field maintenance of the DECstation 5000 Model 100 Series RISC workstation. Field maintenance consists of identifying and replacing failed field replaceable units (FRUs).

Chapters

This guide contains the following chapters:

Chapter 1	Troubleshooting Information
Chapter 2	Troubleshooting Tools
Chapter 3	Part Numbers

Chapter 1, Troubleshooting Information, describes the types of information that help you identify failed FRUs. The types of troubleshooting information are:

- Error messages
- Addresses
- ULTRIX error logs
- Diagnostic LEDs
- Registers

Chapters

Some of the troubleshooting information is automatically displayed, by the system, such as exception messages and diagnostic LEDs. Other information must be specifically generated or accessed by the engineer, such as test error messages, ULTRIX error logs, and registers.

Chapter 2, Troubleshooting Tools, describes the tools that you use to test the system and its components. The troubleshooting tools are:

- Self tests
- Console tests
- Test scripts
- Troubleshooting flowcharts

Chapter 3, Part Numbers, contains tables listing the part numbers for the following types of components:

- Basic system components
- Internal drives
- TURBOchannel option modules
- Monitors
- Input devices
- Cords, cables, and connectors
- Loopback connectors, plugs, test media, and small hardware
- Hardware documentation

Conventions

This guide uses the following conventions:

Monospace type Anything that appears on your monitor screen is set in monospace type, like this.

Boldface type Anything you are asked to type is set in boldface type, like this.

Italic type Any part of a command that you replace with an actual value is set in italic type, like this.

1

TROUBLESHOOTING INFORMATION

Error Messages

An error message can be either an exception message that is automatically displayed when something goes wrong during normal system operation or a test failure message that is displayed when an automatic or user-initiated test fails.

This section describes the following error message types:

- Test failure messages
- Console exception messages
- Memory test error messages

Test failure messages

The test failure message format is:

```
?TFL slot_number/test_name  
(n:description)[module]
```

?TFL	Identifies a test error message
slot_number	Identifies the module that reported the error
test_name	The test that failed
n	Indicates which part of the test failed
description	Describes the failure
module	The module identification number

Table 1-1 lists the test values that can appear in the test failure message when some component part of the base system (slot number 3) fails. The table also lists the recommended corrective action.

For information about test names and corrective action when a TURBOchannel option module fails (slot number 0, 1, or 2), refer to the documentation for the indicated module.

Table 1-1 Base system test error messages

Test Name	Component Tested	Corrective Action
cache/data cache/fill cache/isol cache/reload cache/seg fpu	CPU module	Replace the CPU module. If the problem persists, replace the system module.
mem mem/float10	Memory modules	Troubleshoot according to Figure 2-14.
mem/select	Memory and system module	Replace the memory module failed. If the problem persists, replace the system module.
misc/halt	System module	Replace the system module.
misc/kbd	Keyboard and system module	Troubleshoot according to Figure 2-23.
misc/mouse	Mouse and system module	Troubleshoot according to Figure 2-23.
misc/pstemp	Power supply	Troubleshoot according to Figure 2-21.
misc/wbpart	Memory modules	Troubleshoot according to Figure 2-14.

Table 1-1 (Cont.) Base system test error messages

Test Name	Component Tested	Corrective Action
ni/ellsn ni/common ni/crc ni/cntrs ni/dma1 ni/dma2 line>ni/esar ni/ext-lb ni/int ni/int-lb ni/m-cst ni/promisc ni/regs ni/setup	Base system Ethernet controller	Troubleshoot according to Figure 2-17.
rtc/nvr rtc/period rtc/regs rtc/time	System module	Replace the system module.
scc/access scc/enable scc/io scc/regs scc/pins scc/tx-rx	Serial line controllers and devices attached to them	Troubleshoot according to Figure 2-19.
scsi/cntl scsi/sdiag scsi/target	Base system SCSI controller or device	Troubleshoot according to Figure 2-15.
tlb/prb tlb/reg	CPU module	Replace the CPU module.

Console exception messages

This is a typical console exception message:

```
? PC: 0x451<vtr=nrml>
? CR: 0x810<ce=0,ip4,exc=AdEL>
? SR: 0x30030000
      <cu1,cu0,cm,ipl=8>
? VA: 0x451
? ER: 0x100003f0
? MER: 0x2000
```

PC	The address of the exception instruction
CR	The contents of the cause register. The last term is the exception type. The exception types are as follows: MOD, TLBL, or TLBS: An invalid address was probably used in a console command. AdEL or AdES: A console command probably attempted access on a boundary that was not a word. IBE or DBE: Timeout bus error if MER bits 16, 15, 11, 10, 9, and 8 are all clear. Memory error if one or more of those MER bits is set.
SR	The contents of the status register
VA	The virtual address of the exception
ER	The contents of the error address register
MER	The contents of the memory error register

Memory test error messages

This is a typical memory test error message:

```
?TFL:3/mem(PER,cause=0000001C,  
DBE=0040000c,  
Bank 2, D16-31,d23-d16)
```

Bank	The slot number of the problem memory module
D16-31	The module farthest from the power supply failed.
D0-15	The module nearest the power supply failed.

Addresses

Slot numbers

Table 1-2 Slot numbers in commands and messages

Slot No.	Hardware Identified
0	Option module in slot 0 (farthest from the power supply)
1	Option module in slot 1 (middle option slot)
2	Option module in slot 2 (nearest the power supply)
3	Base system hardware, which includes <ul style="list-style-type: none">- System module- CPU module- Memory modules- Base system SCSI controller- Base system Ethernet controller

Memory addresses

These addresses appear in memory error printouts.

Table 1-3 Memory module slot address ranges

Slot No.	2-Mbyte Module Addresses	8-Mbyte Module Addresses
0	0000000-03FFFFFF	0000000-0FFFFFFF
1	0400000-0FFFFFFF	1000000-1FFFFFFF
2	0800000-0FFFFFFF	2000000-2FFFFFFF
3	0C00000-0FFFFFFF	3000000-3FFFFFFF
4	1000000-1FFFFFFF	4000000-4FFFFFFF
5	1400000-1FFFFFFF	5000000-5FFFFFFF
6	1800000-1FFFFFFF	6000000-6FFFFFFF
7	1C00000-1FFFFFFF	7000000-7FFFFFFF

Hardware physical addresses

These addresses appear in error printouts.

Table 1-4 Hardware physical addresses

Address Range	Indicated Hardware
0x00000000-0x07FFFFFF	Memory array banks 0 to 7
0x08000000-0x0BFFFFFF	Reserved
0x0C000000-0x0DFFFFFF	Memory registers
0x0E000000-0x0FFFFFFF	CPU control ASIC registers
0x10000000-0x13FFFFFF	Slot 0, option module
0x14000000-0x17FFFFFF	Slot 1, option module
0x18000000-0x1BFFFFFF	Slot 2, option module

Table 1-4 (Cont.) Hardware physical addresses

Address Range	Indicated Hardware
0x1C000000-0x1FFFFFFF	Base system, slot 3 in commands and messages, includes the elements listed below
0x1C000000-0x1C03FFFF	System ROM
0x1C040000-0x1C07FFFF	I/O control registers and DMA pointers
0x1C080000-0x1C0BFFFF	Ethernet address PROM
0x1C0C0000-0x1C0FFFFF	Ethernet interface
0x1C100000-0x1C13FFFF	SCC(0) registers
0x1C140000-0x1C17FFFF	Reserved
0x1C180000-0x1C1BFFFF	SCC(1) registers
0x1C1C0000-0x1C1FFFFF	Reserved
0x1C200000-0x1C23FFFF	Real-time clock
0x1C240000-0x1C29FFFF	Reserved
0x1C300000-0x1C33FFFF	SCSI interface
0x1C340000-0x1C37FFFF	Reserved
0x1C380000-0x1C3BFFFF	SCSI DMA
0x1C3C0000-0x1FBFFFFF	Reserved
0x1FC00000-0x1FC3FFFF	Boot ROM
0x1FC40000-0x1FFFFFFF	Reserved

ULTRIX Error Logs

To examine the ULTRIX error logs from the ULTRIX prompt, type

```
/etc/uerf -R | more
```

Table 1-5 Error log event types

Code	Event Type
100	Machine check
101	Memory error
102	Disk error
103	Tape error
104	Device controller error
105	Adapter error
106	Bus error
107	Stray interrupt
108	Asynchronous write error
109	Exception or fault
113	CPU error and status information
130	Error and status registers
200	Panic (bug check)
250	Informational ASCII message
251	Operational message
300	System startup message
310	Time change message
350	Diagnostic information

Error log information varies by event type. The following lists cover three typical event types: memory parity error, CPU write timeout, and bus timeout.

Memory parity error log fields

The following memory error log fields are pertinent when a memory parity error occurs:

The ERROR SYNDROME field identifies the memory parity error.

The MEM REG fields give the following memory failure information:

HARD CNT shows how many errors recurred on both read and write operations.

SOFT CNT shows how many errors recurred on read but cleared on write.

TRAN CNT shows how many errors did not recur on read.

DATA BIT IN ERROR or PARITY BIT IN ERROR indicates whether a data bit or a parity bit failed.

HIGH BYTE IN ERROR or LOW BYTE IN ERROR identifies the byte where the error occurred.

MEMORY PARITY ERROR lists the error type (hard, soft, transient).

D0-15 or D16-31 tells whether the low (left) or high (right) SIMM failed.

BANK tells which bank of memory failed.

The PHYSICAL ADDRESS field identifies the block being read at failure.

CPU write timeout

The following error and status register error log fields are pertinent when a CPU write timeout occurs:

OS EVENT TYPE refers to the error and status registers for a CPU write timeout.

PANIC MESSAGE indicates a CPU write timeout.

The CAUSE register gives no information for a CPU write timeout.

The BAD VIRT ADR register identifies the address of the timeout.

The SIR register shows the write timeout error.

Bus timeout

The following error and status register error log fields are pertinent when a bus timeout occurs:

OS EVENT TYPE refers to the error and status registers for a bus timeout.

PANIC MESSAGE indicates a bus timeout.

The CAUSE register tells that the error occurred during data load or store.

The BAD VIRT ADR register tells the address of the timeout.

Diagnostic LEDs

Table 1-6 LED error codes

LED Error Code (1=On)	Troubleshooting Procedure
1111 1111 0011 1111 0011 1110 0011 1101	Troubleshoot according to Figure 2-3.
0011 0111	Replace the CPU module. If the LEDs display 0011 0111 when the power-up self-test stops, replace the system module.
0011 0110	Troubleshoot according to Figure 2-5.
0010 0011 0001 0011 0000 0011 0000 0000	Troubleshoot according to Figure 2-6.
0011 1011 0010 1011 0001 1011 0000 1011	Troubleshoot according to Figure 2-7.

Table 1-7 Cause register exception codes

Number	Mnemonic	Description
0	Int	Interrupt
1	Mod	TLB modification exception
2	TLBL	TLB miss exception (load or instruction fetch)
3	TLBS	TLB miss exception (store)
4	AdEL	Address error exception (load or instruction fetch)
5	AdES	Address error exception (store)
6	IBE	Bus error exception (instruction fetch)
7	DBE	Bus error exception (data reference: load or store)
8	Sys	Syscall exception
9	Bp	Breakpoint exception
10	RI	Reserved instruction exception
11	CpU	Coprocessor unusable exception
12	OV	Arithmetic overflow exception
13-15		Reserved

System registers

To examine a system register from the console prompt (>>), enter the e command:

```
e [options] [console_address]
```

Table 1-8 System registers

Register	Console Address	Description
SSR	0xBC040100	System support register
MER	0xAC400000	Memory error register
SIR	0xBC040110	System interrupt register
Mask	0xBC040120	System interrupt mask register
MSR	0xAC800000	Memory size register
EAR	0xAE000004	Error address register

**Table 1-9 Memory Error Register (MER)
0x0C400000**

Bits	Access	Description
31:17		Reserved
16	R/W	Page boundary error
15	R/W	Transfer length error
14	R/W	PARDIS memory error disable
13:12		Reserved
11:8	R/W	Byte(s) with parity error
7:0		Reserved

**Table 1-10 System Interrupt Register (SIR)
0x1C040110**

Bits	Access	Description
31	R/W0C	Comm port 1 transmit page end interrupt
30	R/W0C	Comm port 1 transmit DMA memory read error
29	R/W0C	Comm port 1 receive half page interrupt
28	R/W0C	Comm port 1 receive DMA page overrun
27	R/W0C	Comm port 2 transmit page end interrupt
26	R/W0C	Comm port 2 transmit DMA memory read error
25	R/W0C	Comm port 2 receive half page interrupt
24	R/W0C	Comm port 2 receive DMA overrun
23	R/W0C	Reserved
22	R/W0C	Reserved
21	R/W0C	Reserved
20	R/W0C	Reserved
19	R/W0C	SCSI DMA interrupt (DMA buffer pointer loaded)
18	R/W0C	SCSI DMA overrun error
17	R/W0C	SCSI DMA memory read error
16	R/W0C	LANCE DMA memory read error
15	R	Reserved
14	R	NVR mode jumper
13	R	Reserved
12	R	CPU I/O-write timeout interrupt

Table 1-10 (Cont.) System Interrupt Register (SIR) 0x1C040110

Bits	Access	Description
11	R	Reserved
10	R	NRMOD manufacturing mode jumper
9	R	SCSI interrupt from 53C94 SCSI controller
8	R	Ethernet interrupt
7	R	SCC(1) serial interrupt (comm port 2 and keyboard)
6	R	SCC(0) serial interrupt (comm port 1 and mouse)
5	R	TOY interrupt
4	R	PSWARN power supply warning indicator
3	R	Reserved
2	R	SCSI data ready
1	R	PBNC
0	R	PBNO

Note

*Comm port 1 is the same as serial line 2.
Comm port 2 is the same as serial line 3.*

2

TROUBLESHOOTING TOOLS

Self-tests

The system automatically runs a power-up test sequence when you turn the power on. The system runs a quick test or thorough test sequence according to the value of the testaction environmental variable (q for quick, t for thorough). Quick is for normal startup; thorough for troubleshooting.

You can run a self-test sequence from the console prompt without cycling system power.

For the quick test, type:

```
sh slot_number/pst-q
```

For the thorough test, type:

```
sh slot_number/pst-t
```

Console Mode Tests

From the console prompt (>>), enter the `t` command to run an individual test or the `sh` command to run a test script.

Console commands

From the console prompt, enter `?` to see a list of available console commands and their formats.

Table 2-1 Console command functions

Command	Function
<code>?[cmd]</code>	Displays one or more console commands and formats
<code>boot [-zseconds] [-n][bootpath] [-a][args...]</code>	Boots the system
<code>cat slot_number / script_name</code>	Displays the contents of a script
<code>cnfg [slot_number]</code>	Displays system configuration information
<code>d [- (b h w)] [-Scount] rng</code>	Deposits data into memory
<code>e [-b h w] [-c] [-d] [-o] [-u] [-x] [-Scount] rng</code>	Examines memory contents
<code>erl [-c]</code>	Displays the error message log
<code>go [address]</code>	Transfers control to a specific address
<code>init [slot_number] [-m]</code>	Resets the system or a module

Table 2-1 (Cont.) Console command functions

Command	Function
ls [<i>slot_number</i>]	Displays the scripts and other files in a module
passwd [-c] [-s]	Sets and clears the console password
printenv [<i>variable</i>]	Prints environment variables
restart	Attempts to restart the operating system software that is specified in the restart block
script <i>name</i>	Creates a temporary script of console commands
setenv <i>variable value</i>	Sets an environment variable
sh [-b] [-e] [-l] [-v] [-S] [<i>slot_number/script</i>] [<i>arg...</i>]	Runs a script
t [-l] <i>slot_number/test_name</i> [<i>arg1</i>]...[<i>argn</i>]	Runs a test
test	Runs a comprehensive test script that checks the system hardware
unsetenv <i>variable</i>	Removes an environment variable

t command

To run a single test from the console prompt type

t [-**l**] *slot_number/test_name* [*arg1*] [...] [*argn*]

t	is the test command.
-l	The test repeats until you press Ctrl-c or reset the system with the init command or by cycling power.
<i>slot_number</i>	Replace with the slot number of the module to be tested.
<i>test_name</i>	Replace with the name of the test to be run.
<i>arg1...argn</i>	Specify individual test conditions.

Table 2-2 lists the tests for the base system modules. To display a list of tests for an option module from the console prompt (>>), type

t *slot_number/?*

Table 2-2 Base system module tests and utilities

Test or Utility	Command
System module tests:	
Halt button	t 3/misc/halt [<i>number</i>]
Nonvolatile RAM (NVR)	t 3/rtc/nvr [<i>pattern</i>]
Overheat detect	t 3/misc/pstemp
Real-time clock period	t 3/rtc/period
Real-time clock register	t 3/rtc/regs
Real-time	t 3/rtc/time
Serial communication chip (SCC) access	t 3/scc/access
Serial communication chip (SCC) DMA	t 3/scc/dma [<i>line</i>] [<i>loopback</i>] [<i>baud</i>]
SCC interrupts	t 3/scc/int [<i>line</i>]
SCC I/O	t 3/scc/io [<i>line</i>] [<i>loopback</i>]
SCC pins	t 3/scc/pins [<i>line</i>] [<i>loopback</i>]
SCC transmit and receive	t 3/scc/tx-rx [<i>line</i>] [<i>loopback</i>] [<i>baud</i>]

Table 2-2 (Cont.) Base system module tests and utilities

Test or Utility	Command
CPU module tests:	
Cache data	t 3/cache/data [<i>cache</i>] [<i>address</i>]
Cache fill	t 3/cache/fill [<i>cache</i>] [<i>offset</i>]
Cache isolate	t 3/cache/isol [<i>cache</i>]
Cache reload	t 3/cache/reload [<i>cache</i>] [<i>offset</i>]
Cache segment	t 3/cache/seg [<i>cache</i>] [<i>address</i>]
CPU-type utility	t 3/misc/cpu-type
Floating-point unit	t 3/fpu
Translation lookaside buffer (TLB) probe	t 3/tlb/prb
TLB registers	t 3/tlb/reg [<i>pattern</i>]
Memory module tests:	
Floating I/O memory	t 3/mem/float10 [<i>address</i>]
Memory module	t 3/mem [<i>module</i>] [<i>threshold</i>] [<i>pattern</i>]
RAM address select lines	t 3/mem/select
Partial write	t 3/misc/wbpart
Zero memory utility	t 3/mem/init

Table 2-2 (Cont.) Base system module tests and utilities

Test or Utility	Command
Base system Ethernet controller tests:	
Collision	t 3/ni/cllsn
Cyclic redundancy code (CRC)	t 3/ni/crc
Display MOP counters utility	t 3/ni/ctrs
Ethernet-DMA registers	t 3/ni/dma1
Ethernet-DMA transfer	t 3/ni/dma2
Ethernet station address ROM (ESAR)	t 3/ni/esar
External loopback	t 3/ni/ext-lb
Internal loopback	t 3/ni/int-lb
Interrupt request (IRQ)	t 3/ni/int
Multicast	t 3/ni/m-est
Promiscuous mode	t 3/ni/promisc
Registers	t 3/ni/regs
Base system SCSI controller and drives tests:	
SCSI controller	t 3/scsi/cntl
SCSI send diagnostics	t 3/scsi/sdiag <i>scsi_id</i> [d] [u] [s]
SCSI target	t 3/scsi/target <i>scsi_id</i> [w] [lloops]
Keyboard and mouse tests:	
Keyboard	t 3/misc/kbd
Mouse	t 3/misc/mouse

SCSI controller (cntl) test

To test the operation of a SCSI controller from the console prompt, enter

```
t slot_number/scsi /cntl
```

Table 2-3 SCSI controller error codes

(code: description)	Meaning
(1: rd cnfg)	Values written to and read from configuration register did not match.
(2: fifo flg)	First in, first out (FIFO) load and FIFO flags did not match.
(3: cnt xfr)	Write and read operation on TCL register reported a mismatch.
(4: illg cmd)	Command was illegal and did not generate an interrupt.
(5: int reg)	Controller cannot clear internal interrupt register.
(6: rd cnfg)	Mismatch occurred when reading the write/read configuration register.

SCSI send diagnostics (sdiag) test

To run the self-test for an individual SCSI device from the console prompt, enter

```
t slot_number/scsi /sdiagscsi_id [d] [u] [s]
```

Table 2-4 SCSI send diagnostics error codes and descriptions

(code: description)	Meaning
(1: dev ol)	Test could not bring the unit on line.
(2: dev ol)	Test could not bring the unit on line.
(3: sdiag)	Device failed the send diagnostics test.

External loopback test

To check an Ethernet controller and its connections from the console prompt, install a ThickWire loopback connector and enter the following command:

```
t slot_number /ni /ext-lb
```

Table 2-5 External loopback test codes and descriptions

(code: description)	Meaning
(1: (LANCE-init [xxxxxxx]))	LANCE initialization failed. xxxxxxxx is a LANCE failure code.
(3: (xmit [xxxxxxx, yyyyyyy] zzzz))	LANCE initialization failed. xxxxxxxx,yyyyyyy is a LANCE failure code. zzzz describes the likely cause of the failure.
(4: rcv [xxxxxxx,yyyyyyy])	System did not receive packet. xxxxxxxx, yyyyyyy describes the receive failure.
(6: pkt-data !=)	Transmitted packet was not received.
(7)	Fatal error occurred.

Transmit and receive test

To test the transmit and receive function of a serial port from the console prompt (>>), install a communications adapter with an MMJ loopback connector and enter the following command:

```
t 3/scc/tx-rx [line] line loopback [baud] [parity]  
[bits]
```

<i>line</i>	Specify line 0, 1, 2, or 3.
<i>loopback</i>	Specify intl for internal or extl for external.
<i>baud</i>	Specify 300, 1200, 2400, 3600, 4800, 9600, 19200, or 38400.
<i>parity</i>	Specify none, odd, or even.
<i>bits</i>	Specify 8, 7, or 6 bits per character.

Table 2-6 SCC transmit and receive test codes and descriptions

(code: description)	Meaning
1: LnN tx bfr not empty. status=xx	System could not write a single character because the transmit buffer was not empty. The error occurred on line <i>N</i> . <i>xx</i> is the contents of SCC read register 0.
2: LnN char not rcvd. status=xx	Expected CHAR AVAIL signal not received. The error occurred on line <i>N</i> . <i>xx</i> is the contents of SCC read register 0.
3: LnN expctd=xx, rcvd=yy, status=zz	The character received was different from the character transmitted. The error occurred on line <i>N</i> . <i>xx</i> is the transmitted value. <i>yy</i> is the received value. <i>zz</i> is the contents of SCC read register 0.
4: LnN Rx err. errs=xx	Receiving character in FIFO reported an error. The error occurred on line <i>N</i> . <i>xx</i> is the associated input character FIFO error bits.

SCC pins test

To test the pins on a communications connector from the console prompt, install a modem loopback connector on the communications connector and enter the following command:

t 3/scc/pins *line attachment*

line Specify line 2 (right connector) or 3 (left).

attachment Identify the loopback connector: 29-24795, H8571, hm, or H3200

Table 2-7 Pin pairs tested by loopback connectors

Loopback Connector	Pin Pairs Tested	Meaning
29-24795	4-5 23-6-8	RTS to CTS SS to DSR and CD 6-23 failure implies 6 broken. 8-23 failure implies 8 broken. 6-23 8-23 failure implies 23 broken.
H3200	4-5 6-20 12-23	RTS to CTS DSR to DTR SI to SS
H8571-A	4-5 20-6-8	RTS to CTS DTR to DSR and CD 6-20 failure implies 6 broken. 8-20 failure implies 8 broken. 6-20 8-20 failure implies 20 broken.
hm (H8571-A)	4-5	RTS to CTS

Table 2-8 SCC pins test codes and descriptions

(code: description)	Meaning
1:LnN Invld param [xx]	The loopback specifier was invalid. The error occurred on serial line <i>N</i> . <i>xx</i> is the first two characters of the invalid value.
2:LnN Strtup R-xx xptd=yy actl=zz pins	Test failed to generate the expected SCC status bits. The error occurred on serial line <i>N</i> . <i>xx</i> is the number of the SCC register that contains the status bits. <i>yy</i> is the expected status bits. <i>zz</i> is the actual status bits. <i>pins</i> is the pin pairs tested.
3: LnN xxxxx	Pins failed to respond properly. xxxxx is the numbers of one or more pin pairs that failed the test.

Test scripts

To run a test script from the console prompt (>>), type

sh [*options*] *slot_number/test_name*

sh The shell command

options:

- b** Executes script directly, not through a subshell
- e** Script halts on error.
- l** Test loops until Ctrl-c or system reset.
- v** Echos script to console
- S** Suppresses script-not-found error messages


slot_number Replace with the slot number of the module to be tested.

test_name Replace with the name of the script to be run.

To see a list of all test scripts for a module, type


ls *slot_number/?*

Flow Charts




WS33P002

Figure 2-1 Troubleshooting procedure, 1 of 2




WS33P003

**Figure 2-2 Troubleshooting procedure,
2 of 2**




WS33P005

Figure 2-3 When the LED display is 1111 1111, 0011 1111, 0011 1110, or 0011 1101, 1 of 2




WS33P023

Figure 2-4 When the LED display is 1111 1111, 0011 1111, 0011 1110, or 0011 1101, 2 of 2




WS33P007

Figure 2-5 When the LED display is 0011 0110




WS33P017

Figure 2-6 When the LED display is 0010 0011, 0001 0011, 0000 0011, or 0000 0000




WS33P026

Figure 2-7 When the LED display is 0011 1011, 0010 1011, 0001 1011, or 0000 1011, 1 of 2




WS33P027

Figure 2-8 When the LED display is 0011 1011, 0010 1011, 0001 1011, or 0000 1011, 2 of 2



WS33P010

Figure 2-9 When the monitor has no display, 1 of 2



WS33P011

Figure 2-10 When the monitor has no display, 2 of 2






Figure 2-11 When hardware does not appear in the cnfg display, 1 of 3




WS33P009

Figure 2-12 When hardware does not appear in the cnfg display, 2 of 3




WS33P024

Figure 2-13 When hardware does not appear in the cnfg display, 3 of 3




WS33P006

Figure 2-14 Troubleshooting memory modules




WS33P014

Figure 2-15 Troubleshooting SCSI controllers and devices, 1 of 2




WS33P015

Figure 2-16 Troubleshooting SCSI controllers and devices, 2 of 2




WS33P016

Figure 2-17 Troubleshooting an Ethernet controller, 1 of 2




WS33P021

Figure 2-18 Troubleshooting an Ethernet controller, 2 of 2




WS33P018

Figure 2-19 Troubleshooting a printer, modem, or other serial line device, 1 of 2




WS33P019

Figure 2-20 Troubleshooting a printer, modem, or other serial line device, 2 of 2




WS33P004

Figure 2-21 Troubleshooting the power supply




WS33P001

Figure 2-22 If the system unit overheats



WS33P020

Figure 2-23 Troubleshooting the keyboard and mouse, 1 of 2



WS33P022

Figure 2-24 Troubleshooting the keyboard and mouse, 2 of 2




Figure 2-25 When ULTRIX is running but the monitor has no display, 1 of 3





Figure 2-26 When ULTRIX is running but the monitor has no display, 2 of 3

WS33P012



WS33P013

Figure 2-27 When ULTRIX is running but the monitor has no display, 3 of 3

3

PART NUMBERS




Figure 3-1 DECstation 5000 Model 100 Series Major FRUs

3-2 PART NUMBERS

Table 3-1 Part numbers: Basic system components

Item	Part No.	Customer Order No.
System module	70-28336-01	—
CPU module only, 20 MHz	54-20615-01	KN02-BC
CPU module only, 25 MHz	54-20615-02	KN02-CC
Power supply assembly	H7826-AA	—
Power supply fan assembly	70-28334-01	—
Memory module, 2Mb, single	57-30735-02	—
Memory module, 4Mb pair, (two 2Mb modules)	—	MS01-AA
Memory module, 8Mb, single	57-34320-01	—
Memory module, 16Mb pair (two 8Mb modules)	—	MS01-CA
System unit cover	70-28337-01	—
System unit chassis	70-28320-01	—
Removable media drive panel	70-28338-01	—

Table 3-2 Part numbers: Internal drives

Item	Part No.	Customer Order No.
RX23 diskette drive	—	RX23-FL
RX23 diskette drive unit	RX23-A0	—
RX23 diskette drive adapter card	54-19288-01	—
RZ23 hard disk drive	RZ23-E0	—
RZ23L half-height hard disk drive	RZ23L-E0	RZ23L-FL
RZ24 hard disk drive	—	RZ24-FL
RZ24 hard disk drive PCB	29-28144-01	—
RZ24 hard disk drive head disk assembly (HDA)	29-28145-01	—
RRD42 optical compact disc drive	RRD42-AA	RRD42-FL

Table 3-3 Part numbers: TURBOchannel option modules

Item	Part No.	Customer Order No.
1-plane Monochrome Graphics Frame Buffer (MFB)	54-20609-01	PMAG-AB
8-plane Color Graphics Frame Buffer (CFB)	54-19815-01	PMAG-BB
8-plane 2D Graphics Accelerator	54-20314-01	PMAG-CB
8-plane 3D Graphics Accelerator	54-20185-01	PMAG-DB
24-plane 3D Graphics Accelerator	54-20185-02	PMAG-EB
96-plane High-performance 3D Graphics	54-20114-01	PMAG-FB
8-to-24-plane Upgrade	—	PMAG-GB
24-bit Z-buffer Option Module	—	PMAG-HA
8-plane Z-buffer	54-20410-AA	—
16-plane Z-buffer	54-20352-AA	—
ThickWire Ethernet Option Module	54-19874-01	PMAD-AB
SCSI Controller Option Module	54-19876-01	PMAZ-AB

Table 3-4 Part numbers: Monitors

Item	Part No.	Customer Order No.
VR262, 19-inch monochrome monitor, 120 volts	—	VR262-AA
VR262, 19-inch monochrome monitor, 240 volts	—	VR262-A3
VR297, 16-inch color monitor, 120 volts	—	VR297-DA
VR297, 16-inch color monitor, 240 volts, Northern Hemisphere	—	VR297-D3
VR297, 16-inch color monitor, 240 volts, Southern Hemisphere	—	VR297-D4
VR299, 19-inch color monitor, 120 volts	—	VR299-DA
VR299, 19-inch color monitor, 240 volts, Northern Hemisphere	—	VR299-D3
VR299, 19-inch color monitor, 240 volts, Southern Hemisphere	—	VR299-D4
VR319, 19-inch monochrome monitor, 120/240 volts, Northern Hemisphere	—	VR319-DA
VR319, 19-inch gray-scale monitor, 120/240 volts, Northern Hemisphere	—	VR319-CA
VR319, 19-inch monochrome monitor, 240 volts, Southern Hemisphere	—	VR319-D4
VR319, 19-inch gray-scale monitor, 240 volts, Southern Hemisphere	—	VR319-C4

Table 3-4 (Cont.) Part numbers: Monitors

Item	Part No.	Customer Order No.
VRT16, 16-inch color monitor, 120/240 volts, Northern Hemisphere	—	VRT16-DA
VRT16, 16-inch color monitor, 240 volts, Southern Hemisphere	—	VRT16-D4
VRT19, 19-inch color monitor, 120 volts	—	VRT19-DA
VRT19, 19-inch color monitor, 240 volts, Northern Hemisphere	—	VRT19-D3
VRT19, 19-inch color monitor, 240 volts, Southern Hemisphere	—	VRT19-D4

Table 3-5 Part numbers: Input devices

Item	Part No.	Customer Order No.
Keyboard, flat	—	LK201
Keyboard, curved	—	LK401
Mouse	—	VSXXX-AA
Tablet and stylus	—	VSXXX-AB
Lighted programmable function keyboard (LPFK) package, 120 volts	—	VSX20-AA
Lighted programmable function keyboard (LPFK) package, 240 volts	—	VSX20-A3
Programmable function dials (PFD) package, 120 volts	—	VSX30-AA
Programmable function dials (PFD) package, 240 volts	—	VSX30-A3
Combination LPFK and PFD package, 120 volts	—	VSX10-AA
Combination LPFK and PFD package, 240 volts	—	VSX10-A3

Table 3-6 Part numbers: Loopback connectors, plugs, test media, and small hardware

Item	Part No.	Customer Order No.
MMJ loopback connector	12-25083-01	—
ThickWire loopback connector	12-22196-02	—
SCSI chain terminator	12-30552-01	—
ThinWire T-connector	12-25869-01	—
ThinWire terminators	12-26318-01	—
Jumper to clear NVR	12-14314-00	—
Comm-line-to-MMJ adapter	12-33190-01	—
SCSI controller terminator	12-33626-01	—
CPU standoff post	12-35477-01	—
CPU standoff rivet	12-35477-02	—
Comm modem loopback	29-24795-00	—
RX23 bezel insert	74-42126-01	—
Blank bezel insert	74-42126-02	—
RRD42 bezel insert	74-42126-03	—
TZK10 bezel insert	74-42126-04	—

Table 3-7 Part numbers: Cords, cables, and connectors

Item	Part No.	Customer Order No.
Monitor-to-system-unit power cord (U.S.)	17-00442-26	—
System unit or expansion box power cord	17-00606-10	BN19P-K
SCSI expansion-box-to-expansion-box cable	17- 01351-04	BC19J-1E
Keyboard-mouse cable	17-02640-01	—
Serial line cable	—	BC16E-10
SCSI system-unit-to-expansion-box cable	17-02641-02	BC09D-06
SCSI internal data cable for upgrade (RZ23)	17-03175-01	—
ThickWire transceiver cable	17-01321-01	BNE4C-02
ThinWire cable, 12 ft	17-01241-12	BC16M-12
ThinWire LAN kit	22-00112-01	BC16T-12
DESTA ThickWire-to-ThinWire Ethernet adapter	70-22781-02	DESTA-BA
Twisted pair (10 base T) adapter	—	H3350-AA
Video cable, color	17-02906-01	BC29G-09

Table 3-7 (Cont.) Part numbers: Cords, cables, and connectors

Item	Part No.	Customer Order No.
Video cable, grayscale	17-02878-01	—
Video cable, monochrome	17-03054-01	—
SCSI internal data cable	17-03055-01	—
SCSI internal power cable	17-03064-01	—

Table 3-8 Part numbers: Hardware documentation

Item	Part No.	Customer Order No.
DECstation 5000 Model 100 User Documentation Kit	—	EK-PM32A-DK-001
Kit includes the following documents:		
<i>DECstation 5000 Model 100 Installation Guide</i>	—	EK-PM32B-IN-001
<i>DECstation 5000 Model 100 Operator's Guide</i>	—	EK-PM32C-OG-001
<i>DECstation 5000 Model 100 Workstation Reference Card</i>	—	EK-PM32D-RC-001
<i>DECstation 5000 Model 100 Maintenance Guide</i>	—	EK-PM32G-MG-001
<i>DECstation 5000 Model 100 Pocket Reference Guide</i>	—	EK-PM32E-PS-001
<i>TURBOchannel Maintenance Guide</i>	—	EK-TRBOC-MG-003

Table 3-8 (Cont.) Part numbers: Hardware documentation

Item	Part No.	Customer Order No.
Components and Add-Ons:		
<i>RX23 Disk Drive Service Manual</i>	—	
<i>RZ23 Disk Drive Service Manual</i>	—	
<i>RZ23L Disk Drive Service Manual</i>	—	
<i>RZ24 Disk Drive Service Manual</i>	—	
<i>RRD42 Owner's Manual</i>	—	
<i>Installing and Using the LN03</i>	—	EK-0LN03-UG
<i>LN03 PLUS User's Guide</i>	—	EK-LN03S-UG
<i>ScriptPrinter Installation Guide</i>	—	EK-LN03R-UG
<i>ScriptPrinter Operator's Guide</i>	—	EK-LN03R-OG